

## ANTIFOULING COMPATIBILITY CHART

CHOSEN ANTIFOULING		MICRON OPTIMA	COPPERCOAT	MICRON EXTRA MICRON CSC MICRON 66	ULTRA LONGLIFE	CRUISER® SUPERIOR	TRILUX® TRILUX® 33 INTERSPEED 2000	BOTTOMKOTE	VC OFFSHORE WITH TEFLON®
PREVIOUS ANTIFOULING (IN GOOD CONDITION)	MICRON OPTIMA	●	●	●	●	●	●	●	●
	MICRON EXTRA MICRON CSC CRUISER® SUPERIOR COPPERCOAT	●	●	●	●	●	●	●	●
	BOTTOMKOTE	∅	●	∅	∅	∅	∅	●	∅
	TRILUX® INTERSPEED 2000 LONGLIFE VC OFFSHORE ULTRA	●	●	●	●	●	●	●	●
	UNKNOWN PRODUCT	<b>B</b>	<b>B</b>	<b>B</b>	<b>B</b>	<b>B</b>	<b>B</b>	<b>B</b>	<b>B</b>
	PREVIOUS ANTIFOULING IN POOR CONDITION	∅	∅	∅	∅	∅	∅	∅	∅

- KEY:**
- Apply the chosen antifouling directly after an 80 grit wet sand, wash with fresh water and allow to dry.
  - ∅ Remove the antifouling totally.
  - B** Following an 80 grit wet sand apply a barrier coat of Primocon before applying any International antifouling mentioned in this guide.